Section 02260 - DIRECT BORE

1. SCOPE. This section covers direct boring, installation of carrier pipe, and all associated items.

2. INSTALLATION. Pipe called out to be direct bored shall be installed through a bored hole with a diameter approximately the same as the outside diameter at the bell of the pipe to be installed. After the pipe is installed if the maximum space between the pipe and the bore wall is 1 inch or greater, grout shall be pumped through the bore until all space between the pipe and bore wall is filled.

End of Section